

Congrats on your recent purchase of a NOPTIC® Thermal Camera!

The installation is very simple, if you follow these instructions you will avoid the common pitfalls:

1. If you are seeing a black video screen there is a quick solution. Click on the wrench icon which is on the bottom left of the control panel and switch the video settings from PAL to NTSC M. Make sure that the video is set to Composite Preview.
2. Plug Startech directly into MDT not into dock.
3. **Ground** the NOPTIC ECU to a dedicated chassis ground. No splicing or grounding multiple devices to one bolt.
4. **Power** the NOPTIC ECU from a dedicated 12V power source that comes on with the ignition. No Splicing or stealing power off another device. 5amp fuse

